

# RPM Autos - Owner's Quick Guide

Welcome. This quick guide covers basic owner tasks and tips to keep your vehicle reliable.

## A. Starting & Daily Checks:

- Check mirrors and seat position before driving.
- Ensure fuel level and warning lights are normal.

## B. Basic Maintenance:

- Follow scheduled servicing in the manual.
- Use manufacturer recommended oil grade.

## C. Emergency Procedures:

- If engine overheats: stop safely, switch off engine, wait 15 minutes, check coolant reservoir (do not open hot radiator cap).
- Flat tyre: use hazard lights and change tyre only in a safe place or call roadside assistance.

## D. Fuel & Efficiency Tips:

- Keep tyres at recommended pressures.
- Avoid excessive idling and heavy acceleration.

Contact RPM Autos for any support, diagnostics or service bookings.